Intercom connector pins

1 Common

2 Power



XLR3M XLR3F

Headset connector pins



DIP Switch settings & Sidetone adjustment



Loosen slotted screw inside keyhole in belt clip, on back of beltpack.

Swivel belt clip and slide it up and down to expose DIP switch and sidetone adjustment.



DIP switch





Sidetone adjustment

Use small, flat-blade screwdriver to adjust screw inside hole.

DIP Switch settings

- * = defaults
- 1 Select
 - * ON = Dynamic OFF = Electret
- 2 Headset Output Level **ON** = High
 - * OFF = Low
- 3 Min Volume
- * **ON** = Silent at min level **OFF** = Not silent at min level
- 4 LEDs On/Off
 - * **ON** = LEDs normal operation **OFF** = All LEDs dark
- 5 Call-on Talk Enable
- **ON** = Call occurs when talk on * **OFF** = No call when talk on
- 6 Talk Latch Enable
 - * **ON** = Latch enabled **OFF** = Latch disabled



Purchase date

Reseller

www.clearcom.com

HME# 399G034 Rev A 3/20/13



following information:

CLEAR-COM MAKES NO WARRANTIES REGARDING THE PRODUCT, EXPRESS, IMPLIED OR STATUTORY, INCLUDING WITHOUT LIMITATION ANY WARRANTIES OF MERCHANTABILITY, NONINFRINGEMENT OF THIRD PARTY RIGHTS, OR FITNESS FOR A PARTICULAR PURPOSE, ALL OF WHICH ARE EXPRESSLY DISCLAIMED. For your own records, complete the

We encourage you to review the Standard Limited Warranty to determine its coverage, exclusions from coverage and duration. EXCEPT AS SET FORTH IN THE STANDARD LIMITED WARRANTY,

The Clear-Com product that you have purchased is covered by the Clear-Com Standard Limited Warranty, the terms and conditions of which can be found at www.clearcom.com/support/warranty-support-policies.

Fold

Controls, LEDs & Connectors

- I volume control rotates to adjust volume level
- 2 Talk button talk to all on intercom channel
- Press and hold while talking, or tap to latch on
- 3 Talk LED lights when intercom channel active
- **4 Call LED** lights when call button is pressed
- Call button alerts all on intercom channel
- 6 Power LED lit while beltpack power is on

- 7 Intercom cable receptacle
- (3-pin XLR female)





9

102-SH

moJ-realJ





Cut

RS-701 BELTPACK QUICK REFERENCE GUIDE



G Þ 3 2



(elem ALK niq-4) 9 Headset cable receptacle



.A.2.U ni vldmesss lsnif